

Van Dyke Brown

Ferric Ammonium Citrate	10g	30ml Distilled Water
Tartaric Acid	1.5g	30ml Distilled Water
Silver Nitrate	4g	30ml Distilled Water

Make the three solutions separately - add together slowly, then top up with Distilled Water to make 100ml. Store in a dark bottle and leave at least 24hrs before use.

- 1 Coat the paper in a dim (safelight) room (and allow to dry in a dark environment) Use a Hake Brush or Glass Rod for best results.
- 2 Expose contact negative with UV based on your DMax exposure time (See Digital Negatives Download).
- 3 Wash for 3 mins in tap water with a pinch of Citric Acid. (Change water at least 3 times)
- 4 OPTIONAL - Gold Tone ('Clerc's Formula') approx 25ml per 10x8 and discard (do not reuse)
- 5 Quick rinse 30 seconds in tap water

Sodium Thiosulfate	12.5g
Clean Tap Water	500ml

- 6 Fix in Sodium Thiosulfate for 5 mins (discard after 10, 10x8 prints). This is when the print regains its dark brown colouration and contrast.
- 7 Wash in Clean Tap Water for 10 mins (agitate and use 3 water changes if in trays)